

Contents

Page no

1. Safety	4
2. Description	5
2.1. Meter Description	5
2.2. Symbols Used on LCD Display	6
3. Operation	6
3.1. AC Current Measurements	6
3.2. AC Voltage Measurement	7
3.3. DC Voltage Measurement	7
3.4. Resistance Measurement	7
3.5. Capacitance Measurements	8
3.6. Frequency Measurements	8
3.7. Temperature Measurements	8
3.8. Continuity Measurements	8
3.9. Diode Test	9
3.10. Non-Contact AC Voltage Measurements	9
4. Button	9
4.1. MODE/VFD Button	9
4.2. HOLD/Flashlight Button	10
4.3. RANGE Button	10
4.4. PEAK/INRUSH Button	10
4.5. REL/Backlight Button	10
5. Automatic Power OFF	11
6. Maintenance	11
6.1. Cleaning and Storage	11
6.2. Battery Replacement	11
6.3. Temperature Probe Replacement	11
7. Specifications	12
7.1. Specifications	12
7.2. General Specifications	14

1. Safety

1.1. International Safety Symbols



This symbol, adjacent to another symbol or terminal, indicates the user must refer to the manual for further information.



This symbol, adjacent to a terminal, indicates that, under normal use, hazardous voltages may be present.



Double insulation.



Application around and removal from uninsulated hazardous live conductors is permitted.

1.2. SAFETY NOTES

- Do not exceed the maximum allowable input range of any function.
- Do not apply voltage to meter when resistance function is selected.
- Set the function switch OFF when the meter is not in use.
- Remove the battery if meter is to be stored for longer than 60 days.

1.3. WARNINGS

- Set function switch to the appropriate position before measuring.
- When measuring volts do not switch to current resistance modes.
- Do not measure current on a circuit whose voltage exceeds 600V.
- When changing ranges always disconnect the test leads from the circuit under test.

1.4. CAUTIONS

- Improper use of this meter can cause damage, shock, injury or death. Read and understand this user manual before operating the meter.
- Always remove the test leads before replacing the battery or fuses.
- Inspect the condition of the test leads and the meter itself for any damage before operating the meter. Repair or replace if damaged before use.
- Use great care when making measurements if the voltages are greater than 25VAC RMS or 35VDC. These voltages are considered a shock hazard.
- Always discharge capacitors and remove power from the device under test before performing Diode, Resistance or Continuity tests.
- Voltage checks on electrical outlets can be difficult and misleading because of the uncertainty of connection to the recessed electrical contacts. Other means should be used to ensure that the terminals are not "live".
- If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.


Input Limits

Function	Maximum Input
A AC	600A DC/AC
V AC/DC	1000V DC/AC
Resistance, Capacitance, Frequency, Diode Test, Temperature	300V DC/AC

2. Description


2.1. Meter Description

1. Non-Contact Voltage Detector
2. Current Clamp
3. Non-Contact Voltage Indicator
4. Clamp Trigger
5. Function Switch
6. LCD Display
7. HOLD and Flashlight Button
8. REL and Backlight Button
9. RANGE Button
10. MODE and VFD Button
11. PEAK and INRUSH Button
12. Battery Cover
13. COM Input Jack
14. V, Ω , $\rightarrow$, $\rightarrow$, $\rightarrow$, CAP, TEMP Input Jack



2.2. Symbols Used on LCD Display

- | | |
|--------------------------------|--|
| 1. REL/DCA Zero | 10. Variable Frequency Drive Voltage Value |
| 2. Alternating Current/Voltage | 11. Diode Test |
| 3. Direct Current/Voltage | 12. Continuity |
| 4. Minus Sign | 13. Auto Power Off |
| 5. Low Battery | 14. Fahrenheit and Celsius Units (Temperature) |
| 6. Auto Range Mode | 15. Unit of Measure Prefixes |
| 7. INRUSH Current Mode | 16. Percent (Duty Ratio) |
| 8. Hertz [Frequency] | 17. The Displayed Area |
| 9. Maximum/Minimum | |
| 10. Display Hold | |



3. Operation

NOTES: Read and understand all Warning and Caution statements in this operation manual prior to using this meter. Set the function select switch to the OFF position when the meter is not in use.

3.1. AC Current Measurements

WARNING: Ensure that the test leads are disconnected from the meter before making current clamp measurements.

1. Set the Function switch to the **600A** range. If the approx. range of the measurement is not known, select the highest range then move to the lower ranges if necessary.
2. Press the **REL** button to zero the meter display.
3. Use Rotary Function switch to select AC **60A 600A** range.
4. Press the trigger to open jaw. Fully enclose only one conductor. For optimum results, center the conductor in the jaw.
5. The clamp meter LCD will display the reading.



INCORRECT



CORRECT

3.2. AC Voltage Measurement

1. Insert the black test lead into the negative **COM** terminal and the red test lead into the positive **V** terminal.
2. Set the function switch to the **VAC** position.
3. Connect the test leads in parallel to the circuit under test.
6. Read the voltage measurement on the LCD display.

3.3. DC Voltage Measurement

1. Insert the black test lead into the negative **COM** terminal and the red test lead into the positive **V** terminal.
2. Set the function switch to the **VDC** position.
3. Connect the test leads in parallel to the circuit under test.
4. Read the voltage measurement on the LCD display.

3.4. Resistance

1. Insert the black test lead into the negative **COM** terminal and the red test lead into the **V** positive terminal.
2. Set the function switch to the Ω .CAP position.
3. Touch the test probe tips across the circuit or component under test.
4. Read the resistance on the LCD display.

3.5. Capacitance Measurements

WARNING: To avoid electric shock, discharge the capacitor under test before measuring.

1. Set the function switch to the Ω , CAP position.
2. Insert the black test lead banana plug into the negative **COM** jack and the red test lead banana plug into the **V** positive jack.
3. Touch the test probe tips across the part under test. If "OL" appears in the display, remove and discharge the component.
4. Read the capacitance value in the display.
5. The display will indicate the proper decimal point and value.

Note: For very large values of capacitance measurement it can take several minutes before the final reading stabilizes.

3.6. Frequency Measurements

1. Insert the black test lead banana plug into the negative **COM** jack and the red test lead banana plug into the **V** positive jack.
2. Set the function switch to the **V~HZ/%** Position.
3. Press **MODE** button to select the Frequency (**Hz**) or Duty cycle (**%**).
4. Touch the test probe tips across the part under test.
5. Read the value on the display.
6. The display will indicate the proper decimal point and value.

3.7. Temperature Measurements

1. Set the function switch to the **TEMP** position.
2. Insert the Temperature Probe into the negative **COM** and the **V** positive jacks, observing polarity.
3. Touch the Temperature Probe head to the device under test. Continue to touch the part under test with the probe until the reading stabilizes.
4. Read the temperature on the display. The digital reading will indicate the proper decimal point and value.
5. Use the **MODE** button to select °F or °C.

WARNING: To avoid electric shock, be sure the thermocouple probe has been removed before changing to another measurement function.

3.8. Continuity Measurements

1. Insert the black test lead into the negative COM terminal and the red test lead into the **V** positive terminal.
2. Set the function switch to the  position.
3. Use the **MODE** button to select continuity "". The display icons will change when the MODE button is pressed.
4. Touch the test probe tips across the circuit or component under test.
5. If the resistance is < 50 Ω , a tone will sound.

3.9. Diode Test

1. Insert the black test lead banana plug into the negative **COM** jack and the red test lead banana plug into the **V** positive jack
2. Turn the function switch to  **→** position.
3. Use the **MODE** button to select the diode function if necessary (diode symbol will appear on the LCD when in Diode test mode)
4. Touch the test probe tips to the diode or semiconductor junction under test. Note the meter reading
5. Reverse the test lead polarity by reversing the red and black leads. Note this reading
5. The diode or junction can be evaluated as follows:
 - If one reading displays a value (typically 0.400V to 0.900V) and the other reading displays **OL**, the diode is good.
 - If both readings display **OL** the device is open.
 - If both readings are very small or '0', the device is shorted.

3.10. Non-Contact AC Voltage Measurements

WARNING: Risk of Electrocution. Before use, always test the Voltage Detector on a known live circuit to verify proper operation

1. Touch the probe tip to the live conductor or insert into the live side of the electrical outlet.
2. If AC voltage is present, the detector light will illuminate.

NOTE: The conductors in electrical cord sets are often twisted. For best results, rub the probe tip along a length of the cord to assure placing the tip in close proximity to the live conductor.

NOTE: The detector is designed with high sensitivity. Static electricity or other sources of energy may randomly trip the sensor. This is normal operation.

4. Button

4.1. MODE/VFD (Variable Frequency Drive) Button

- Press MODE/VFD key to select the double measurement functions. This key is active in VAC/Hz/%VFD, Ω /CAP,  **→** position to select among resistance test. diode test. continuity test. HZ%, and in Temp position to select between °C or °F.
- Press and hold the **MODE/VFD** key and turn the selection switch to turn the system on, the auto power off function will be cancelled.
- Press and hold the **MODE/VFD** key for 2 seconds to switch to VFD.

4.2. HOLD/Flashlight Button

- To freeze the LCD reading, press the **Hold/Flashlight** button.
- While data hold is active, the **HOLD** icon appears on the LCD.
- Press the **Hold/Flashlight** button again to return to normal operation.
- Press the **Hold/Flashlight** button to turn the Flashlight on, Press again to turn the Flashlight off.

4.3. RANGE Button

- Press the **RANGE** key to activate the manual mode and to disable the Autorange function.
- The symbol "AUTO" disappears from the upper left part of the display.
- In manual mode, press the **RANGE** key to change measuring range: the relevant decimal point will change its position.
- The **RANGE** key is not active in positions $\gg \rightarrow$, CAP, Hz%, Temp.
- In Autorange mode, the instrument selects the most appropriate ratio for carrying out measurement.
- If a reading is higher than the maximum measurable value, the indication "**OL**" appears on the display.
- Press and hold the **RANGE** key for more than 1 second to exit the manual and restore the Autorange mode.

4.4. PEAK/INRUSH Button

- In AC voltage test mode, press **PEAK/INRUSH** key, the peak maximum and peak minimum values can be measured.
- In current test mode, Press **INRUSH** key the inrush current values are measured.

4.5. REL/Backlight Button

- Press the **REL** button to view the stored value. "**REL**" will flash in the display.
- To exit this mode, press and Hold the **REL** button until "**REL**" is no longer in the display.
- DCA measurements press the **REL** button to zero the display
- Press and hold the **REL/Backlight** button to turn the Backlight on, press and hold again to turn the Backlight off.

5. Automatic Power OFF

- In order to conserve battery life, the meter will automatically turn off after approximately 15 minutes. To turn the meter on again, turn the function switch to the **OFF** position and then to the desired function position.
- Press and hold the **MODE/VFD** key and turn the selector switch to turn the system on, the auto power off function will be cancelled.

6. Maintenance

WARNING: To avoid electrical shock, disconnect the meter from any circuit, remove the test leads from the input terminals, and turn OFF the meter before opening the case. Do not operate the meter with an open case.

6.1. Cleaning and Storage

- Periodically wipe the case with a damp cloth and mild detergent; do not use abrasives or solvents.
- If the meter is not to be used for 60 days or more, remove the battery and store it separately.

6.2. Battery Replacement

1. Rotate Battery Door Lock 180 degrees to open the battery door.
2. Open the battery compartment.
3. Replace the 3 x 1.5V AAA batteries.
4. Secure the battery compartment.

6.3. Temperature Probe Replacement

Note: To use a Type K thermocouple probe that is terminated by a subminiature (flat blade) connector, a subminiature-to-banana plug adaptor is required.

7. Specifications

7.1. Specifications

Function	Range	Resolution	Accuracy $\pm$ (% of reading+digits)
AC True RMS Current	60.00A	10mA	$\pm(2.0\% + 8 \text{ digits})$
	600.0A	100mA	$\pm(2.5\% + 8 \text{ digits})$

Over range protection: Maximum input 600A.

Accuracy specified from 5% to 100% of the measuring range.

Frequency Response: 50Hz to 60Hz True RMS.

Inrush current Maximum Input: 600A

Function	Range	Resolution	Accuracy $\pm$ (% of reading+digits)
AC True RMS Voltage (with VFD)	6.000V	1mV	$\pm(1.0\% + 5 \text{ digits})$
	60.00V	10mV	$\pm(1.2\% + 5 \text{ digits})$
	600.0V	100mV	
	1000V	1V	$\pm(1.5\% + 5 \text{ digits})$

Variable frequency drive test AC voltage range: 100V---600V

AC voltage bandwidth: 50 to 1000Hz (sine): 50/60 (all wave)

Accuracy specified from 5% to 100% of the measuring range

Maximum Input: 1000V AC RMS. Peak Maximum Input: 1000V

Function	Range	Resolution	Accuracy $\pm$ (% of reading+digits)
DC Voltage	6.000V	1mV	$\pm(0.9\% + 3 \text{ digits})$
	60.00V	10mV	$\pm(1.0\% + 3 \text{ digits})$
	600.0V	100mV	
	1000V	1V	$\pm(1.2\% + 3 \text{ digits})$

Maximum Input: 1000V DC

Function	Range	Resolution	Accuracy $\pm$ (% of reading+digits)
Resistance	600.0 Ω	0.1 Ω	$\pm(1\% + 4 \text{ digits})$
	6.000k Ω	1 Ω	$\pm(1.5\% + 2 \text{ digits})$
	60.00k Ω	10 Ω	
	600.0k Ω	100 Ω	
	6.000M Ω	1k Ω	$\pm(2.0\% + 5 \text{ digits})$
	60.00M Ω	10k Ω	$\pm(3.0\% + 8 \text{ digits})$

Input Protection: 300V DC or 300V AC RMS

Function	Range	Resolution	Accuracy $\pm$ (% of reading+digits)
Capacitance (Auto-ranging)	99.99nF*	0.01nF	$\pm(4.5\% + 20 \text{ digits})$
	999.9nF	0.1nF	$\pm(3.0\% + 5 \text{ digits})$
	9.999 μ F	0.001 μ F	
	99.99 μ F	0.01 μ F	
	999.9 μ F	0.1 μ F	$\pm(5\% + 5 \text{ digits})$
	9.999mF	0.001mF	
	99.99mF	0.01mF	

Input Protection: 300V DC or 300V AC RMS.

* < 99.99nF (no specification)

Function	Range	Accuracy $\pm$ (% of reading+digits)
Frequency with Test Leads (AC Voltage)	10Hz to 100kHz	$\pm(1.0\% + 5 \text{ digits})$

Input Protection: 1000V AC RMS

Sensitivity: > 15V AC RMS

Frequency (AC Current)

Function	Range	Accuracy $\pm$ (% of reading+digits)
Frequency (AC Current)	45Hz to 1kHz	$\pm(1.0\% + 5 \text{ digits})$

Sensitivity: > 20A

Function	Range	Resolution	Accuracy $\pm$ (% of reading+digits)
Duty Cycle	20.0% to 80.0%	0.1	$\pm(1.2\% + 10 \text{ digits})$

Function	Range	Resolution	Accuracy $\pm$ (% of reading+digits)
Temperature	-20.0 to 1000°C	0.1/1°C	$\pm(3\% + 3^\circ\text{C})$
	-4.0 to 1832°F	0.1/1°F	$\pm(3\% + 5^\circ\text{F})$

Sensor: Type K Thermocouple

Input Protection: 300V DC or 300V AC RMS.

Function	Testing Condition	Reading
Diode	Forward DCA is approx .1mA, open circuit voltage MAX 3V	Forward voltage drop of Diode
Continuity	Test current MAX 1.5mA	Buzzer makes a long sound, While resistance is less than (50 Ω)

Input Protection: 300V DC or 300V AC RMS.

7.2. General Specifications

Clamp jaw opening	33mm approx.
Display	6000 counts backlit LCD
Low Battery indication	"  " is displayed
Over-range indication	"OL" display
Measurement rate	3 readings per second, nominal
Temperature sensor	Type K thermocouple
Input Impedance	10M (VDC and VAC)
AC response	True RMS (AAC and VAC)
ACV Bandwidth	50 - 1000Hz
Operating Temperature	5 to 40°C (41 to 104°F)
Storage Temperature	-20 to 60°C (-4 to 140°F)
Operating Humidity	Max 80% up to 31°C decreasing linearly to 50% at 40°C
Storage Humidity	<80%
Operating Altitude	2000 meters maximum.
Battery	Three (3) x 1.5V AAA Battery
Battery life	-30h (Backlight ON). -1 00h(Backlight OFF)
Auto power OFF	After approx. 15 minutes
Dimensions	239 x 72 x 40mm
Weight	318g
Safety	For indoor use and in accordance with the requirements for double insulation to IEC1010-1 (2001): EN61010-2-030 EN61010-2-032 EN61010-2-033 Overvoltage Category III 600V, Pollution Degree 2.



MAJOR TECH (PTY) LTD

South Africa

 www.major-tech.com

 sales@major-tech.com

Australia

 www.majortech.com.au

 info@majortech.com.au

